



## SUPER MAGNETIC PAINT

- 1 MEASURE THE AREA**
- Carefully measure the area you wish to cover and ensure you have enough paint. This tin covers 5 sq. metres / 54 sq. ft. with 4 coats.

- 2 PREPARE THE SURFACE**
- Ensure the surface is clean and dry. Check and fill any holes or cracks in the surface with a normal decorator's filler.
  - Apply one coat of Smart White Primer to prepare the surface.

- 3 APPLY THE PAINT**
- We recommend 4 coats of paint.
  - Use roller or brush to apply. (If roller, use a short pile sleeve to ensure a smooth finish).
  - Apply first coat by applying a smooth even coat.
  - Allow to dry.

- 4 SAND THE SURFACE**
- Lightly sand between coats. Ensure finished surface is smooth.

- 5 ALLOW TO DRY**
- Allow the surface to dry for a minimum of 24 hours before overcoating or applying a paint colour, digital print or wallcovering of your choice.

- 6 MAGNETS**
- For best performance, we recommend using Smart Neo-Magnets (available from [www.smartersurfaces.com](http://www.smartersurfaces.com)) or any high quality neodymium magnets.

**Note:**

Ordinary household magnets are not suitable.

### GET EVEN MORE FUNCTIONALITY

Consider adding dry erase functionality with Smart Dry Erase Wallcovering or Smart Wall Paint.



**Support:**

**Email:**  
[support@smartersurfaces.com](mailto:support@smartersurfaces.com)

**Phone (Ire):**  
+353 1 412 6200

**Website:**  
[www.smartersurfaces.com](http://www.smartersurfaces.com)